

At times it is desirable to cover unused Latches, Receivers or Mortise cuts on wall panels or table edges, etc. For this purpose we have designed these plastic Cover Plates



**Fig 1** Here a **CP2S-1 Cover Plate** is shown concealing a Type 2 Small Receiver. The arrow points to a cover button. (See TDS 127)



**Fig 2** **CP2-1** and **CP3-1 Cover Plates** conceal a Type 2 Large Receiver and a Type 3 Latch. The arrow points to a cover button. (See TDS 127)




**Fig 3**




**Fig 4**

**Fig 3 & Fig 4** Cover Plates are designed to be snapped into the empty mortise or into the Norse Latch and Receiver cases.



## Cover Plates for Type 2 Small, Type 2 Large and Type 3 Latches and Receivers



These Snap-In Plates cover the mortised-in latches and receivers or the unoccupied mortise itself

These cover plates are reusable and paintable

